




## Description


The VH heater allows the valve to operate even in harsher environmental conditions, extending the temperature range below the nominal values specified in the catalog.

## Technical specifications

Power supply	24 V AC / DC
Power consumption	20-30 W
Heating temperature IP	80-120 °C
Protection rating	IP43
Material	Aluminum and stainless steel
Standards	CE and RoHS compliance




## Electrical connections



## Installation instructions

- 1) Lift the valve stem and clean the surface of the stem and the stuffing box.
- 2) Assemble the heating unit.
- 3) Secure the heating component with the appropriate clamps.
- 4) Install the actuator and complete the mechanical assembly.



### Safety notes:

Ensure that the power supply is disconnected before performing any installation work.  
Do not exceed the maximum specified temperature to avoid damage.  
Use only original components for repairs.